

OEL Recommended Spare Parts List

ML1120



Revision 22a

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000				
	Printer general Assy	3	43560101	Cover Assy.-Access	1	1	2	4				-
	Printer general Assy	4	43484801	Cover Rear	1	1	2	4				-
15	Printer general Assy	4	44428101	Cover-Rear	1	1	2	4	For Rev. B0, D0~			-
	Printer general Assy	5	43514501	Ribbon_Protector Assy	1	5	10	20				-
	Printer general Assy	6	43478701	Tractor Assy	1	2	4	8				-
15	Printer general Assy	6	44428202	Tractor-Assy	1	2	4	8	For Rev. B0, D0~			-
	Printer general Assy	7	43482501	Pull Up Roller Unit	1	2	4	8				-
8	Printer general Assy	12	44056001	Platen_Knob	1	2	4	8				-
	Printer general Assy	15	43560201	Sheet_Guide Assy	1	1	2	4				-
	Printer general Assy	16	43514901	Wire_guide_rear	2	2	4	8				-
	Printer general Assy	17	43655701	Pull_up_guide	1	2	4	8				-
	Lower_Cover Assy	7	43440802	Board-L09 (OEL Maintenance parts)	1	3	6	12	OEL CENTRO+RS+USB			-
	Lower_Cover Assy	7	43440804	Board-L09 (OEL Maintenance parts)	1	3	6	12	OEL CENTRO+RS			-
21	Lower_Cover Assy	7	45165801	R09-PCB Assy.maintenance Spec.	1	3	6	12	For Rev. C0 of OEL CENTRO+RS+USB	*1 >For Rev. A0, B0=*1~*6 is set exchange. >For Rev. C0=*1,*6 is set exchange.		-
	Lower_Cover Assy	8	43703802	PWR unit-ACDC Switch	1	3	6	12	For 220VAC~240VAC			-
21	Lower_Cover Assy	8	44752802	PWR unit-ACDC Switch	1	3	6	12	For Rev. C0~ of 220VAC~240VAC	*2 For Rev. A0, B0=*1~*6 is set exchange.		-
	Lower_Cover Assy	9	43560001	POW Cord Bending Figure	1	3	6	12				-
21	Lower_Cover Assy	9	44304601	CONN Cord-Wire Power- DC	1	3	6	12	For Rev. C0~	*3 For Rev. A0, B0=*1~*6 is set exchange.		-
	Lower_Cover Assy	10	43390801	CONN Cord-RS232C	1	3	6	12	Only RS			-
21	Lower_Cover Assy	19	44204203	Power Cable Assy	1	-	-	-	For Rev. C0~	*5 For Rev. A0, B0=*1~*6 is set exchange.		-
	Cover_Upper Assy	1	43483701	Cover_Upper	1	1	2	4				-
	Cover_Upper Assy	3	43483801	Sheet Operation Panel	1	1	2	4				-
	Cover_Upper Assy	4	43483901	OP Panel Frame	1	1	2	4				-
	Cover_Upper Assy	5	43516302	Board-LS0 (PD432 Maintenance parts)	1	3	6	12				-
20	Cover_Upper Assy	6	2381118P0001	20624FWR1. 25-13-130	1	3	6	12				-
	Ribbon_Protector Assy	1	43476201	Ribbon_Protector_Brac ket	1	5	10	20				-
	Ribbon_Protector Assy	2	43498001	Ribbon_Protector	1	5	10	20				-
10	Printer_Unit	4	SPP3-10SUS	Pin	4	3	6	12	For ODA and OEL only. It is not possible to arrange excluding ODA and OEL.	This part permits the maintenance exchange by the selling company responsibility by the requirement from ODA or OEL.		-
10	Printer_Unit	9	43475301	Carriage_Shaft	1	1	2	4	For ODA and OEL only. It is not possible to arrange excluding ODA and OEL.	This part permits the maintenance exchange by the selling company responsibility by the requirement from ODA or OEL.		-
	Printer_Unit	10	43502802	Head	1	20	40	80				-
	Printer_Unit	12	43473701	Stepping_Motor	1	5	10	20				-
	Printer_Unit	13	43487901	Gear 9	1	2	4	8				-
	Printer_Unit	14	43509701	Stepping Motor	1	5	10	20				-
	Printer_Unit	15	43473901	Ribbon Feed Assy	1	2	4	8				-
	Printer_Unit	16	43640701	Idle_pulley_bracket(W eld)	1	2	4	8				-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000				
	Printer_Unit	17	43640801	Washer_idle_pulley	1	2	4	8				-
	Printer_Unit	18	43473801	Idle Pulley	1	2	4	8				-
	Printer_Unit	19	43475001	Spring(Plate tension)	1	2	4	8				-
11	Printer_Unit	25	43478601	Shaft_Release	1	2	4	8				-
13	Printer_Unit	26	2071052P0001	SSS-57-2AU	1	3	6	12				-
22	Printer_Unit	27	40135301	Photo-Interrupter	1	3	6	12	Apply untill S/N:AW37*****			-
22	Printer_Unit	27	6520028M0001	GP1A173LCS2F	1	3	6	12	Apply from S/N:AW38*****		A	
	Printer_Unit	28	43519401	CONN Cord-Sensor (6P)	1	5	10	20				-
	Printer_Unit	29	43536701	sensor_arm	1	1	2	4				-
	Printer_Unit	31	43475201	Leaf_Spring	1	2	4	8				-
15	Printer_Unit	31	44750701	Spring-Leaf	1	2	4	8	For Rev. B0, D0~			-
	Printer_Unit	32	43480401	Platen_Coller_L	1	1	2	4				-
	Printer_Unit	33	43480201	Platen Assy	1	10	20	40				-
	Printer_Unit	36	43476901	Adjust_Knob	1	1	2	4				-
	Printer_Unit	39	43477301	Pull up gear	1	1	2	4				-
	Printer_Unit	42	43477601	Change washer	1	1	2	4				-
	Printer_Unit	43	43477701	Release lever	1	1	2	4				-
	Printer_Unit	45	43532801	GAP SW	1	3	6	12				-
	Printer_Unit	46	43519501	CONN Cord-Sensor (7P)	1	5	10	20				-
9	Printer_Unit	54	44197901	Label-Caution	1	1	2	4				-
19	Carriage Assy	1	44860901	Carriage-Sub-Assy	1	1	2	4	For ODA and OEL only. It is not possible to arrange excluding OEL. When apply this parts, please apply 44197901 (Label-Caution) at the same time.	This part permits the maintenance exchange by the selling company responsibility by the requirement from ODA or OEL.		
	Carriage Assy	3	43476301	SP_Belt	1	3	6	12				-
	Carriage Assy	4	43476401	Guide_Cable	1	1	2	4				-
	Carriage Assy	9	43559801	Head Cord (16) Bending Figure	1	3	6	13				-
	Carriage Assy	11	43514301	Clamp_Head_Cable	1	1	2	4				-
22	Carriage Assy	12	40135301	Photo-Interrupter	1	3	6	13	Apply untill S/N:AW37*****			-
22	Carriage Assy	12	6520028M0001	GP1A173LCS2F	1	3	6	13	Apply from S/N:AW38*****		A	
	Carriage Assy	13	43519301	CONN Cord-Sensor (3P)	1	5	10	20				-